


Supplement to the operating instructions for the optional Display and Control unit

## LT 1 Lambda Transmitter



The following symbols are used in these operating instructions as important safety notes for the user. They appear within each chapter where the information is required. The safety notes, in particular the warnings, must always be observed and followed.



**WARNING**

Identifies possible hazards to personnel, especially through electric power.



**WARNING**

Indicates possible hazards to personnel caused by improper handling of system parts.



**ATTENTION!**

Indicates risk to system parts or a possible adverse effect on functions.



**NOTE:**

Contains important additional information for the user about the system or system parts, and offers further tips.

Appears in texts containing instructions for carrying out an action.

In this context the user is urged to observe the statutory accident prevention measures during all works, and to do everything in accordance with the situation to prevent damage to persons and property.

---

# Contents

---

<b>Safety notes</b>	<b>2</b>	<b>Digital inputs</b>	<b>23 - 24</b>
		Idle state	23
<b>Introduction</b>	<b>4</b>	Functions A, B, C, D	24
		Status	24
<b>Display</b>	<b>5 - 11</b>	<b>Appendix</b>	<b>25 - 29</b>
Menu bar	5	<b>Tables</b>	<b>25 - 26</b>
Menu function [meas]	6	Parameters associated with digital inputs	25
Menu function [cal]	6 - 7	Parameters associated with limit values	26
Menu function [par]	8	Parameters associated with digital outputs	26
Menu function [psw]	8		
Menu function [view]	9	<b>Parameter groups</b>	<b>27 - 28</b>
Menu function [change]	10		
Menu function [diag]	11	<b>Menu overview</b>	<b>29</b>
<b>Display parameters</b>	<b>12 - 13</b>		
Brightness, contrast and language	12		
Customer password input, parameter 1472	13		
<b>Limit values</b>	<b>14 - 21</b>		
Standard configuration (4 fixed limit values)	14		
Limit value configuration	14		
Limit value 1 (2, 3, 4) acts on			
Min. comparison value/			
Max. comparison value	14		
Constant limit max./constant limit min.	15		
Reset mode	15		
Trigger delay	15		
Load-dependent limit curves, fuel-specific limit values	16		
2 fuels à 4 limit curves/			
Limit values per fuel	16		
4 fuels à 2 limit curves/			
Limit values per fuel	17		
Limit curves/limit values	17 - 18		
Input of limit curves/limit values	19		
Display and resetting of limit values	20		
Display of limit value crossing	20		
Calling up limit value settings	21		
Resetting limit values via the display	21		
Return to main menu	21		
<b>Digital outputs (relays)</b>	<b>22</b>		
Idle state	22		
Functions A, B, C, D	22		
Position	22		

# 1. Introduction

## 1. Introduction

These operating instructions describe how to use the optional display and control unit for the lambda transmitter LT 1; they do not replace the operating instructions for the LT 1 transmitter.


Fig. 1 shows the display and control unit for the lambda transmitter LT 1. It consists of an LCD display, the cursor keys, the Enter key and the menu keys.



- The cursor keys serve to select measured values, parameters or functions within the display readout. The keys also position the cursor for Input and for Editing (amendments).
- The Enter key activates the editing mode and confirms and ends
- The menu keys correspond to the menu item shown above them.

In Fig. 1, the menu keys have the following functions, from left to right: Measurement [**meas**], Calibration [**cal**], Parameter setup [**par**], Diagnostics [**diag**].

Fig. 1



The menu keys are identified by the LT 1 Lambda Transmitter's functions, in abbreviated English form:

**measurement**, **calibration**, **parameter setup**, **diagnostics**



Note: The limit values are only displayed if they were activated via parameters 930 / 940 / 950 / 960 ("Service" clearance level).

## 2. Display

### 2. Display

The display is divided into three areas (Fig. 2):

1. The status row at the top of the display. It shows:

- On the left, whether the maintenance mode is activated.
- At the centre, the current operational status.
- On the right, whether warnings or faults are present in the system.
- Faults are also indicated by the status row flashing.

2. The measured value is shown at the centre of the display area.

3. The menu bar, whose input is controlled by the menu key located underneath.




Fig. 2

### 2.1. The menu bar



The menu bar illustrated above is activated when the LT 1 is switched on. The functions shown on the menu bar are interpreted as follows:

- [ **meas** ] alternates between indication of all measured values in tabular form, and a large display of the selected value. This value is selected with the up/down cursor keys.
- [ **cal** ] opens the calibration functions menu.
- [ **par** ] opens the menu for viewing and amending the parameters.
- [ **diag** ] alternates between displaying the O<sub>2</sub> value, and displaying warnings and/or faults.

The first function shown in the menu bar of opened submenus is [ **exit** ]. This function serves to quit the submenu and return to the higher-level menu.




Note: Menu overview in the Appendix → fold-out page

## 2. Display

### 2.2 The menu function **meas**

Pressing the **[meas]** key switches the display to a large representation (shown in Fig. 2, page 5) of the value selected via the up/down cursor keys. Pressing the **[meas]** key repeatedly switches the display back to a listing of all the measured values.



### 2.3 The menu function **cal**

Pressing the **[cal]** menu key displays four calibration functions (Fig. 3):

- Start autom. calibration
- Start autom. Check up
- Start manual calibration with cal. pump
- Start manual calibration without cal. pump

The required calibration function is selected via the up/down cursor keys. The ENTER key confirms the selected function and triggers this calibration procedure.

The automatic calibration modes can be interrupted via the menu function:

**Interrupt calibration, return to measurement function.**

During manual calibration, the calibrated value can be changed via the menu function:

**Change calibrated value, LS1 probe (Fig. 4).**




Fig. 3




Fig. 4

## 2. Display

---

After calling up this menu function, the amendment procedure in the displayed submenu can be terminated with the **[cancel]** key. Alternatively, the amended O<sub>2</sub> value can be accepted with the **[OK]** key.

Manual calibration is interrupted or ended with **End calibration, return to measurement function** (the amended O<sub>2</sub> value is preserved).



**Note:** The Manual calibration mode remains active for a maximum of 15 minutes (this is set at the factory). This is followed by switching back automatically to the measurement mode. The maximum manual calibration time can be changed via parameter 288 at service level.

If the **[cal]** menu is called up during cold start, the measurement gas pump can be switched on.

A substitute O<sub>2</sub> value is displayed during calibration procedures. Measurement or display of a meaningful O<sub>2</sub> value is only possible in the operational mode, i.e. after the end of calibration.



**ATTENTION:** The operating instructions of the lambda transmitter LT 1 must always be observed !

## 2. Display

### 2.4 The menu function **par**

After calling up the **[par]** menu, the menu opens up for the parameters (Fig. 5). Access to the parameter menu is divided into the following clearance levels:

- Operational level
  - Customer level
  - Service level
  - Factory level
- } (only accessible via password)



**Note:** The customer level password can be set freely by the customer, see 3.2.

The current clearance level is shown on the display. The available menu functions are displayed in the menu bar:

- **[ exit ]** returns to start menu.
- **[ psw ]** allows changing the clearance level via password input.
- **[ view ]** displays the parameter settings. All the parameters are displayed, regardless of clearance level.
- **[ change ]** allows the changing of parameters: only the parameters accessible at the clearance level are displayed.



**Note:** Over 2000 parameters can be changed via the various clearance levels. In order to avoid confusion, use of the **[change]** function is recommended.




Fig. 5

#### 2.4.1 The menu function **psw**

**[psw]** calls up the password input menu. The operational clearance level\* is displayed. The functions visible in the menu bar mean:

- **[ exit ]** returns to the **[par]** menu.
- **[ clear ]** resets the clearance level to operational level\*
- **[ --- ]** shifts to the alphabetically previous input letter.
- **[ + + + + ]** shifts to the alphabetically next input letter.

The up/down cursor keys act similarly to **[ + + + + ]** and **[ --- ]**. Left/right move the input point along the password.

Once the correct password is entered, the corresponding clearance level is displayed and is retained on leaving the menu with **[exit]**.

If no key is pressed for some time, the clearance level is reset to the operational level.\*

\* If the customer clearance level is still at the factory setting, the customer level is set.



## 2. Display

### 2.4.2 The menu function **view**

**[ view ]** opens the parameter menu. The menu bar is interpreted as follows:  
**[exit ]** returns to the menu function **[par ]**  
**[ s/l ]** toggles between display formats:

Short: only the parameter number and the current value are displayed.

```

Measure
***Display***
P. 970: 38
P. 971: 10
P. 972: English
exit | s/l | group- | group+
  
```

Fig. 6

Medium: the parameter number and the current value are accompanied by a short description.

```

Measure
***Display***
Contrast
P. 970: 38
Brightness
P. 971: 10
Language
P. 972: English
exit | s/l | group- | group+
  
```

Fig. 7

Long: as **Medium**, but with an additional parameter status row displayed.

```

Measure
***Display***
Contrast
P. 970: 38
*kw*_30____[12;42]____
Brightness
P. 971: 10
*bw*_10 [0;15]
exit | s/l | group- | group+
  
```

Fig. 8

**[ group- ]** scrolls back one parameter group.  
**[ group+ ]** scrolls forward one parameter group.

All available parameter groups are summarised in the appendix.

The left/right cursor keys correspond to the key-functions of:

**[group-]** and **[group+]** respectively.

If not all the parameters in a group are visible in the readout, this is indicated by flashing arrows in the right-hand margin. The up/down cursor keys can be used to shift the parameters and make them visible.

As an example, we explain below the status row shown in the **Long** format:

- **\*kw\*\_30\_\_\_\_[ 12 ; 42 ]\_\_\_\_**  
The asterisks and underline characters (\* and \_) are fillers.
- **K** indicates the customer clearance level  
(b = operation, k = customer, s = service, f = manufacturing)
- **W** indicates the parameter type  
(write = revisable, read = read only).
- **30** is the default value (base value in EPROM)
- **[ 12 ; 42 ]** is the possible range within which the parameter can be changed

For some parameters there is no default value and interval!

## 2. Display

### 2.4.3 The menu function

#### **change**

**[change]** allows parameter values to be amended. The menu bar for the submenu is the same as the **[view]** menu (see 2.4.2).

However, here the parameter to be changed is shown inverted (light characters on a dark background). The required parameter can be selected via the up/down cursor keys. The edit mode (change mode, Fig. 9) for that parameter is activated with the **[ENTER]** key. The parameter's value flashes during editing.

The parameter can now be changed via the up/down cursor keys (and left/right for multidigit parameters). The menu bar functions are interpreted as follows:

- **[ esc ]** returns to the **[change]** menu without accepting the changed parameter.
- **[ dflt ]** sets the default value.
- **[ OK ]** accepts the changed value and returns to **[ENTER]** or **[change]** menu.

This procedure leads back to the **[change]** menu. Further parameters can be called up and changed.




Fig. 9

Selected parameters are indicated in three ways:

- 1. Inverted representation** → parameter can be changed
- 2. Outlined representation** → parameter cannot be changed
- 3. Flashing representation** → active editing mode (change mode)



## 3. Display Parameters

### 3.1 Brightness, contrast and language

The parameter group **\*\*\*Display\*\*\*** controls the LT 1 Lambda Transmitter's Display and Control unit, with the following parameters:

P. 970            Contrast  
This parameter serves to set the display contrast.

P. 971            Brightness  
This parameter controls the display's background brightness.

P. 972            Language  
The language of the output text (German, English) can be selected.




Fig. 10

#### 3.1.1 Brightness and contrast via the cursor keys

Brightness and contrast can also be changed via the cursor keys, as follows:



Contrast +    → Keys 1 & 2  
Contrast -    → Keys 3 & 4  
Brightness + → Keys 1 & 4  
Brightness - → Keys 2 & 3  
Press the appropriate two keys simultaneously

### 3. Display Parameters

#### 3.2 Customer password input

##### Parameter 1472

The password for the customer level can be selected individually by the customer. In order to enter a new password, at least the customer clearance level must be activated.

The new password must be entered as parameter 1472 (see Fig. 11).



**ATTENTION:** The password is accepted by the system a few seconds after input, and is displayed as "####". Thus, an entered password can never be read out.




Fig. 11



**Note:** The password is set to "0000" at the factory. Since this corresponds to the password input default setting, the customer level can be activated by switching briefly to password input and leaving it again without making any changes.

---

## 4. Limit values

---

### 4. Limit values

Measured data can be monitored with the help of limit values. The LT 1 Lambda Transmitter comes with 4 fixed limit values as standard, that can be freely configured. Load-dependent limit curves and fuel-specific limit values are available as option 657R0920.

#### 4.1 Standard configuration ( 4 fixed limit values )

Monitoring takes place by comparing the current value with a lower limit (Min. comparison value) and with an upper limit (Max. comparison value). If the monitored value falls outside the range (window), i.e. it is smaller than the Min. comparison value or greater than the Max. comparison value, the limit value output is set.

Parameters 910 to 914 indicate whether the limit value is set.

The limit values 1 - 4 can be used to switch the LT 1 transmitter's relay outputs. The settings that need to be made are described in the chapter about digital outputs (chapter 5). The limit value configurations, the display and resetting of limit values are described below. When using the display, these items can be found in the parameter groups limit value config. and limit values. The relevant parameter numbers are listed in the Appendix, table on page 19.

#### 4.1.1 Limit value configuration

Each of the 4 limit values has seven parameters, used for configuration (e.g. for limit value 1):

1. **Li 1 acts on** (see 4.1.1)
2. **1: Max. comparison value** (see 4.1.1.2)
3. **1: Min. comparison value** (see 4.1.1.2)
4. **1: Const. limit max.** (see 4.1.1.3)
5. **1: Const. limit min.** (see 4.1.1.3)
6. **1: Reset mode** (see 4.1.4)
7. **1: Triggering delay** (see 4.1.5)

The parameters are preceded by the number of their corresponding limit value.

#### 4.1.1.1 Limit value 1 (2,3,4,) acts on

This parameters specifies which value is to be monitored. The following values are available for monitoring:

Parameters: 930/940/950/960

- **Off** - the limit value is not in use at the moment.
- **O<sub>2</sub> measured value**
- **Values available for configuration:** one of 6 measured values definable by the user is being monitored.
- **Temperature LS 1\***
- **Absolute pressure\***
- **Current LS 1**
- **Voltage LS 1** ( \* optional )

#### 4.1.1.2 Min. comparison value Max. comparison value

Three possible settings are available for the upper and lower comparison values:

Parameters: 931/932  
941/942  
951/952  
961/962

**Off:** The comparison value is not activated.

**Constant value:** A constant reference value is chosen to serve as a comparison value, see 4.1.1.3.

**Calculated**

**Analogue value:** A value calculated from the actual O<sub>2</sub> value or from an analogue input serves as a reference value. In the LT 1 lambda transmitter, one of 12 available reference values can be selected. Configuration of the analogue values to be calculated: see separate instructions.

---

## 4. Limit values

---

### 4.1.1.3 Constant limit max. Constant limit min.

**Parameters:** 933/934  
943/944  
953/954  
963/964

If a constant value is selected to serve as the reference value, this constant is stored in Li Max. or Min. Please note that only integers can be entered. If the constant reference value is displayed with decimal places, the sequence of digits should be entered but the decimal point ignored.

#### Example 1:

The measured O<sub>2</sub> value needs to be monitored. The limit value output is set as follows:

If dropping below 5.5 or exceeding 15.6 vol.% O<sub>2</sub>.

A constant value is specified for the Min. and Max. reference values:

- For the constant Li Max.: 156
- For the constant Li Min.: 55



#### Note:

If the measured value is to be monitored only for exceeding the maximum or only dropping below the minimum, the threshold should be set such that it is never encountered.

Example: The measured O<sub>2</sub> value needs to be monitored only for falling below the minimum. Set the Max. limit value to 30% (300).

#### Example 2:

The probe temperature (optional) needs to be monitored. The temperature is shown on the display in °C. The limit values should be specified as integers in °C. An input of 380 corresponds to 380°C.

### 4.1.4 Reset mode

**Parameters:** 935/945/955/965

If the limit value is set as a result of the reference value being crossed (in either direction), this parameter describes the limit value's resetting mode. Three possibilities are available:

**Automatic:** If the monitored value is changed so that once again it lies within the limit min. and limit max. range, the limit value output is reset **automatically to off**.

**Manual:** The limit value output must be reset manually via the display, via one of the digital inputs or via the remote software (s. Limit values). In this resetting mode, limit values can only be reset if the monitored value lies within the acceptable range.

**Acknowledge:** The limit value output must be reset either manually via the display, via one of the digital inputs or via the remote software (s. limit values). If the monitored reference value is still outside the acceptable range it is only acknowledged to begin with, and disappears on entering the acceptable range.

### 4.1.5 Triggering delay


**Parameters** 936/946/956/966

This parameter can be used to set a triggering delay in the range 0 to 600 seconds. The limit value output is only set if the monitored reference value lies outside the limit min. and limit max. range for longer than the specified period. If the reference value is once again within the limit min. and limit max. limits, the time counter is reset. The triggering delay starts to count again from 0 when limit min. or limit max. is exceeded in the relevant direction.

## 4. Limit values/curves

### 4.2 Load-dependent limit curves, fuel-specific limit values (option 657R0920)

- Load-dependent limit curves,  
The load value (burner load) or some other measured value is switched on via analogue input 4. Instead of fixed limit values, fuel-specific curves of 2 to a maximum of 8 checkpoints can be entered.



Limit curves (factory setting), with parameters set for distinguishing between situations

#### Possible combinations

Alternatively

- 2 fuels à 4 limit curves / limit values per fuel
- 4 fuels à 2 limit curves / limit values per fuel

#### 4.2.1 2 fuels à 4 limit curves / limit values per fuel

Limit values 1 to 4 are used (Li 1 ... Li 4)

Allocation of limit curves / limit values

Curve	Function	Fuel	Calculated analogue value
5	LiC1/Li1	1	9
6	LiC1/Li1	2	9
7	LiC2/Li1	1	10
8	LiC2/Li2	2	10
9	LiC3/Li3	1	11
10	LiC3/Li3	2	11
11	LiC4/Li4	1	12
12	LiC4/Li4	2	12

LiC → Limit curve

Li → Limit



## 4. Limit values

### 4.2.2 4 fuels à 2 limit curves / limit values per fuel

Limit values 1 and 3 are used (Li 1 and Li 3)

Allocation of limit curves / limit values

Curve	Function	Fuel	Calculated Analogue value
5	LiC1/Li1	1	9
6	LiC1/Li1	2	9
7	LiC1/Li1	3	9
8	LiC1/Li1	4	9
9	LiC3/Li3	1	11
10	LiC3/Li3	2	11
11	LiC3/Li3	3	11
12	LiC3/Li3	4	11

LiC → Limit curve

Li → Limit

### 4.2.3 Parameter setup (factory settings)

#### 4.2.3.1 Analogue input 4

Par. 602: "Analogue input 4"  
Par. 603: "Curve 4"  
Par. 604: 3,9 mA  
Par. 605: 20,1 mA  
Par. 606: "Off"  
Par. 607: "Off"

Display of the load value via configurable measured value 6

Par. 800: "Calc. Analogue value 4"  
Par. 801: "Burner load"  
Par. 809 : "%"  
Par. 812: "XXXX"  
Par. 813: "0,4s"

Conversion 4...20 mA  $\triangleq$  0...100% for load specification (burner load) via curve 4, as follows:

Parameter	Value
2150	x1 4000 [4 mA]
2151	y1 20 [20 %]
2152	x2 20 000 [20mA]
2153	y2 100 [100%]

## 4. Limit values/curves

### 4.2.3.2 Limit curves / Limit values



Parameter setup for the 4 limit curves takes place via the analogue calculations 9 to 12.

**Attention:** Fuel selection "Par. 836 Digital inputs" must be switched on.

- Limit curve 1 Analogue calc. 9:  
Par. 652: "Calculates analogue val. 4"  
Par. 653: "Curve 5"  
Par. 654: "Off"  
Par. 657: "Curve +BS" (at manufacturing level)
- Limit curve 2 Analogue calc. 10:  
Par. 662: "Calculates analogue val. 4"  
Par. 663: "Curve 7"  
Par. 664: "Off"  
Par. 667: "Curve +BS" (at manufacturing level)
- Limit curve 3 Analogue calc. 11:  
Par. 672: "Calculates analogue val. 4"  
Par. 673: "Curve 9"  
Par. 674: "Off"  
Par. 677: "Curve +BS" (at manufacturing level)
- Limit curve 4 Analogue calc. 12:  
Par. 682: "Calculates analogue val. 4"  
Par. 683: "Curve 11"  
Par. 684: "Off"  
Par. 687: "Curve +BS" (at manufacturing level)

If, instead of the limit curves, fixed limit values are to be specified, then parameters 930, 931, 940, 941, 950, 951, 960, 961 should be adjusted accordingly, see 4.1.1.2 and 4.1.1.3.

The following settings are made at the factory:

Limit value 1 / limit curve 1

- Par. 930: "O<sub>2</sub> measured value" or some other measured value to be monitored  
Par. 931: "Off" (upper limit value)  
Par. 932: "Calc. analogue value 9"  
Par. 935: Resetting mode "Automatic"  
Par. 936: Triggering delay to 0 seconds

Limit value 2 / limit curve 2

- Par. 940: "O<sub>2</sub> measured value" or some other measured value to be monitored  
Par. 941: "Off" (upper limit value)  
Par. 942: "Calc. analogue value 10"  
Par. 945: Resetting mode "Automatic"  
Par. 946: Triggering delay to 0 seconds

Limit value 3 / limit curve 3

- Par. 950: "O<sub>2</sub> measured value" or some other measured value to be monitored  
Par. 951: "Off" (upper limit value)  
Par. 952: "Calc. analogue value 11"  
Par. 955: "Automatic" resetting mode  
Par. 956: Triggering delay to 0 seconds

Limit value 4 / limit curve 4

- Par. 960: "O<sub>2</sub> measured value" or some other measured value to be monitored  
Par. 961: "Off" (upper limit value)  
Par. 962: "Calc. analogue value 12"  
Par. 965: Resetting mode "Automatic"  
Par. 966: Triggering delay to 0 seconds

---

## 4. Limit values/curves

---

### 4.2.4 Input of limit values/ limit curves

See also tables in 4.2.1 and 4.2.2

Factory settings – Direct triggering in the event of falling below these values after a delay of 0 seconds

#### Limit curve 1 / Fuel 1

x1 --- x5            Burner load  
y1 --- y5            O<sub>2</sub> limit values (curves)

Max. 8 curve-points possible  
Distribution can be freely chosen!

Parameter	Value
2200	x1    20 [20 % ]
2201	y1    30 [3,0 % O <sub>2</sub> ]
2202	x2    40 [40 % ]
2203	y2    25 [2,5 % O <sub>2</sub> ]
2204	x3    60 [60 % ]
2205	y3    20 [2,0 % O <sub>2</sub> ]
2206	x4    80 [80 % ]
2207	y4    18 [1,8 % O <sub>2</sub> ]
2208	x5    100 [100%]
2209	y5    15 [1,5 % O <sub>2</sub> ]

#### Limit value curve 2 / Fuel 1

Parameter	Value
2300	x1    20 [20 % ]
2301	y1    25 [2,5 % O <sub>2</sub> ]
2302	x2    40 [40 % ]
2303	y2    20 [2,0 % O <sub>2</sub> ]
2304	x3    60 [60 % ]
2305	y3    15 [1,5 % O <sub>2</sub> ]
2306	x4    80 [80 % ]
2307	y4    10 [1,0 % O <sub>2</sub> ]
2308	x5    100 [100%]
2309	y5    5 [0,5 % O <sub>2</sub> ]

## 4. Limit values

### 4.3 Limit values

#### Display and resetting

The limit values' current status as well as resetting limit values, make use of the display in the limit values group; the relevant parameter numbers are shown in the Appendix, table on page 19.

#### Parameters 910 to 914

The parameters limit value 1, limit value 2, limit value 3 and limit value 4 indicate the limit values' current settings and status. **Off** means that either the corresponding limit value is not in use, or the monitored reference value is within the limits Li Min. and Li Max. If a limit value is shown as "set", the monitored reference value is or was outside those limits.

#### Parameters 914 to 917


Resetting the limit value output proceeds with the help of the parameters Reset Li 1, Reset Li 2, Reset Li 3 and Reset Li 4, provided that the manual or acknowledge reset mode was selected. In order to reset a limit value, "Reset" must be entered in the corresponding parameter. However, resetting in the manual mode is only possible if the monitored reference value is within the limits Li Min. and Li Max.

**Off:** Off means either that the relevant limit value is not in use, or the monitored reference value is within the limits Li Min. and Li Max.

**Acknowledged:** If Acknowledged is shown for a limit value, the monitored reference value is outside the acceptable range and the deviation from the limit values has already been acknowledged.



**Set:** If a limit value is shown as "set", the monitored reference value lies outside the limits Li Min. and Li Max.

#### 4.3.1 Display of limit value crossing (In preparation)



Following activation of the limit value parameters 930/940/950/960, "Service" clearance level, the display shows Li1, Li2, Li3, Li4 depending on which limit value has just been activated.

Crossing the limit value in either direction is shown as follows:

- Li 1  ..... means limit value 1 has been crossed upwards
- Li 2  ..... means limit value 2 has been crossed downwards


## 4. Limit values

### 4.3.2 Calling up limit value settings (in preparation)

- Press the "diag" (Diagnostics) key  
Use the cursor keys to select the appropriate limit value  
The selected limit value is highlighted by a frame



- Press the ENTER key  
The limit value's current setting appears on the display, see illustration.



- Explanation:**
- ① Limit value 1 is parameterised for the measured O<sub>2</sub> value
  - ② Switching points: Upward crossing 10.0 vol.% O<sub>2</sub>  
Downward crossing 3.0 vol.% O<sub>2</sub>
  - ③ Currently measured O<sub>2</sub> value 6.7 Vol.% O<sub>2</sub>
  - ④ limit value not set.

Possible states:

- set → Limit value was triggered
- Off → Measured value in acceptable range
- acknowledged → Limit value crossing has already been acknowledged

### 4.3.3 Resetting limit values via the display

Proceed as described in 4.3.2, and in addition press the Reset key.

### 4.3.4 Return to main menu

Press the Exit key x2.

---

## 5. Digital outputs (Relays)

---

### 5. Digital outputs (Relays)

Up to 7 digital outputs can be freely configured in the LT 1 lambda transmitter. The same parameters are available for the configuration of each digital output. These are:

- Idle state (see 5.1)
- Four functions that trigger a switching procedure; the four functions are OR-ed (see 5.2)
- Display of the current relay position (see 5.3)

#### Factory assignment of the digital outputs

Output 1 → Accumulated faults  
Output 2 → Accumulated warnings  
Output 3 → Calibration  
Output 4 → Maintenance  
Output 5 → Not configured  
Output 6 → Not configured  
Output 7 → Not configured

#### 5.1 Idle state

**Parameters: 1030/1040/1050/1060**

This is where the idle state is set. This state is present if none of the four functions triggers a switching procedure. The setting Diagnostics allows the idle state to be changed via the parameter Position (see below). Idle state (see 5.1)

- Low (operating current principle)
- High (idle current principle)
- Diagnostic operation

#### 5.2 Function A,B,C,D

**Parameters 1031 bis 1034  
1041 bis 1044  
1051 bis 1054  
1061 bis 1064**

The four functions are structured almost identically; an operational state can serve as a switching criterion. If a **Limit value** (Li 1-4) is selected as a switching criterion, the output switches if the limit value's output is set. E.g., if **Calibration** is chosen as a switching criterion, the output is not in the idle state during calibration.

Each function (A, B, C, D) can have all operational states as the switching criterion; however, the allocation of limit values Li 1-4 and/or test gases is restricted to individual functions. **Limit value 1** and **Test gas 1** are only possible with **Function A**, analogously **Limit value 2** and **Test gas 2** with **Function B** etc. However, all combinations can be set by OR-ing the four functions.

The following operational states can be selected as switching criteria:

- Warning
- Fault
- Calibration
- Checking
- Cold start
- Measurement
- Standby
- Maintenance
- Limit values 1 - 4
- Test gas 1 - 2
- No measurement

#### 5.3 Position

**Parameters: 1039/1049/1059/1069**

This parameter indicates the current switching state. Manual switching of the output is possible by changing the parameter via diagnostic operation.

---

## 6. Digital inputs

---

### 6. Digital inputs

8 digital inputs can be configured for the LT 1 Lambda Transmitter. The inputs switch position according to the applied voltage: **High** (voltage = 24 V) or **Low** (input open or voltage = 0 V).

Depending on this position, the LT 1 transmitter can carry out certain actions. All 8 digital inputs are identical with regard to structure and functionality. The inputs' configuration is controlled by the following parameters:

#### Factory assignment of the digital inputs

input 1 → Pump on  
Input 2 → Calibration triggering  
Input 3 → Check triggering  
Input 4 → Cyclic calibration triggering  
Input 5 → Fault reset  
Input 6 → <sup>(1)</sup> Fuel 2  
Input 7 → <sup>(1)</sup> Fuel 3  
Input 8 → <sup>(1)</sup> Fuel 4

<sup>(1)</sup> Parameter 836 Service level must be set to "Digital inputs".  
If no signal preset → Heating oil EL.

#### 6.1 Idle state

**Parameters 1170/1180/1190/1200  
1210/1220/1230/1240**

This is where the digital inputs' idle state is set. If the position differs from that set here, the actions specified by the functions (A, B, C, D) is carried out. If **Diagnostic operation** is set here, the functions (A, B, C, D) can be triggered for the appropriate digital input via the parameter Position.

- Low (operating current principle)
- High (idle current principle)
- Diagnostic operation

## 6. Digital inputs

### 6.2 Functions A, B, C, D

#### Parameters 1171 - 1174

1181 - 1184

1191 - 1194

1201 - 1204

1211 - 1214

1221 - 1224

1231 - 1234

1241 - 1244

The four functions are structured almost identically. However, the allocation of limit values Li 1-4 and/or fuels is restricted to the individual functions (A, B, C, D). Resetting of limit value 1 and Fuel 1 are only possible with function A; analogously, resetting of limit value 2 and Test gas [sic] 2 only with function B, and so on.

The following actions are possible:

- **None**
- **Pump on** activates the measurement gas pump\*
- **Calibration** triggers an automatic calibration
- **Checking** triggers an automatic check
- **Cyc. Cal.** increments an internal counter; when it reaches a particular value (parameter 272), an automatic calibration is triggered and the counter is reset.
  
- **Fault reset** acknowledges present faults
- **Warning reset** acknowledges present warnings
- **Reset Li 1 - 4** (function A) resets limit value 1; functions B, C, D reset limit values 2, 3, 4
- **Fuel 1** (only function A) selects fuel 1; functions B, C, D select fuels 2, 3, 4
- **No cal.** as long as a signal is applied to this input, the system cannot carry out calibration. If a calibration is still in progress, it is immediately terminated.
- **PID control unit on / off** Provided the PID control unit option is activated, this function allows the PID control unit to be turned off.



**\* Warning:** Never draw exhaust gas across the cold probe. This could lead to a blockage in the critical nozzle.  
Observe waiting times:  
With gas and heating oil EI 1 hr  
With coal and heating oil S 2 hrs  
with refuse burning 3 hrs  
If the pump is switched on by mistake, switch mains voltage off and back on!

### 6.3 Status

#### Parameters 1175

1185

1195

1205

1215

1225

1235

1245

This parameter indicates the digital input's state.

The three possible states are **inactive** (idle state) and **active**; the set functions (A, B, C, D) are triggered.

The digital input's state can be set manually with this parameter, provided the parameter Idle level is set to **Diagnostic operation**.



## Appendix: Tables

Parameters associated with digital inputs		
Parameter group digital input 1, 2, 3 .....		
Parameter number	Description	Access
1170, 1180, 1190,...	Idle level, digital input 1, 2, 3,.. (0 = low, 1 = high, 2 = Diagnostic operation)	variable
1171, 1181, 1191,...	Function A, B, C, D of digital input 1, 2, 3, 4	variable
1172, 1182, 1192,...	0 = None 1 = Pump on                      6 = Warning reset	
1173, 1183, 1193,...	2 = Calibration                7 = Reset Li1 / Li2 / Li3 / Li4	
1174, 1184, 1194,...	3 = Check                        8 = Fuel 1 / 2 / 3 / 4	
etc.	4 = Cycl. calibr.                9 = No calibration (blocked) 5 = Faults reset                10 = PID control unit off	
1175, 1185, 1195,...	State of digital input 1,2,3,... (0=Off, 1=Active)	variable

## Appendix: tables

Parameters associated with limit values		
Parameter group limit values		
Parameter number	Description	Access
910 - 913	Display of state of limit value 1/2/3/4, 0 = Off, 1 = Active	read only
914 - 917	Manual reset of limit value 1/2/3/4, set to 1 or trigger to reset	variable
Parameter group limit value configuration		
Parameter number	Description	Access
930 (940, 950, 960)	Selection of the monitored quantity for limit value 1 (2, 3, 4) 0 = None, 1 = O2 value, 2...7 = configurable measured value 1 [sic]... 7, 8 = LS1 temperature, 9 = LS1 pressure, 10 = LS1 current, 11 = LS1 voltage	
931 (941, 951, 961)	Form for comparison value Max with Li 1 (2, 3, 4) 0 = Off, 1 = Const. value, 2...13 = Calculated analogue value 1...12	variable
932 (942, 952, 962)	Form for comparison value Min with Li 1 (2, 3, 4) 0 = Off, 1 = Const. value, 2...13 = Calculated analogue value 1...12	variable
933 (943, 953, 963)	Constants for comparison value Max with Li 1 (2, 3, 4) (only with 931, 941, 951, 961 = fixed value) variable	variable
934 (944, 954, 964)	Constants for comparison value Min with Li 1 (2, 3, 4) (only with 931, 941, 951, 961 = fixed value) variable	variable
935 (945, 955, 965)	Reset mode for limit value 1 (2, 3, 4) 0 = Automatic, 1 = Manual, 2 = Acknowledge	variable
936 (946, 956, 966)	Triggering delay for limit value 1, 2, 3, 4 (in sec)	variable

Parameters associated with digital outputs			
Parameter group digital outputs 1 (2, 3 ... 7)			
Parameter number	Description	Clearance for	Access
1030, 1040, 1050, ...	Idle level 0 = Down, 1 = Up, 2 = Diagnostic operation	Service	variable
1031, 1041, 1051, ...	Function A 0 = Off, 1 = Warning, 2 = Fault, 3 = Calibration, 4 = Check, 5 = Cold start, 6 = Measurement, 7 = Standby, 8 = Maintenance, 9 = Li 1, 10 = Probe 1,2,3,4, 11 = No measurement	Service	variable
1032, 1042, 1052, ...	Function B As function A, but 9 = Li 2, 10 = Probe 2	Service	variable
1033, 1043, 1053, ...	Function C As function A, but 9 = Li 3, 10 = Probe 3	Service	variable
1034, 1044, 1054, ...	Function D As function A, but 9 = Li 4, 10 = Probe 4	Service	variable
1039, 1049, 1059, ...	Momentary position (can be changed in diagnostic operation) 0 = Down, 1 = Up	Service	variable

---

## Appendix: Parameter groups

---

Meas.values 1	Analogue output 1 530
Operational data 40	Analogue output 2 540
Counters and times 70	Analogue output 3 550
Commands 104	Analogue output 4 560
Hardware options 120	Analogue input 1 570
LS1 Sliding voltage 130	Analogue input 2 580
LS1 Probe heating 150	Analogue input 3 590
Meas.gas pump 170	Analogue input 4 600
Norm. cold start 200	Analogue calculation 5 610
Int. cold start 220	Analogue calculation 6 620
LS1 Checks 250	Analogue calculation 7 630
LS1 Calibration 270	Analogue calculation 8 640
Ageing compensation 300	Analogue calculation 9 650
Test gases 330	Analogue calculation 10 660
O2 meas.value config. 360	Analogue calculation 11 670
Monitor output 380	Analogue calculation 12 680
MEV heating 400	Measured value config. 700
Pressure compensation 420	Fuel config. 835
Pressure measurement 440	Limit values 910
Temperature compensation 450	Limit value config. 930
Modbus RS232 480	Display 970
	Software version 985

---

## Anhang: Parametergruppen

---

Relay 1	1030	Relay 2	1040	Relay 3	1050	Relay 4	1060	Relay 5	1070	Relay 6	1080	Relay 7	1090	Magnetic valves	1100	Pump diagnostics	1150	Digital input 1	1170	Digital input 2	1180	Digital input 3	1190	Digital input 4	1200	Digital input 5	1210	Digital input 6	1220	Digital input 7	1230	Digital input 8	1240	Service times	1260	LS1 linearisation	1280	Bus interface	1300	LS1 Dynamic monitoring	1330	PID Control unit	1350	PID Control unit config.	1361	PID Control unit status	1380	Password/serial no.	1472	Parameter CRC 16	1490	Probe data	1500	Cal. history 1	1600	Cal. history 2	1620	Cal. history 3	1640	Cal. history 4	1660	Cal. history 5	1680	Cal. history 6	1700	Cal. history 7	1720	Cal. history 8	1740	Cal. history 9	1760	Cal. history 10	1780	Table Ri LS1	1800	Faults history	1900	Curve 1	2000	Curve 2	2050	Curve 3	2100	Curve 4	2150	Curve 5	2200	Curve 6	2250	Curve 7	2300	Curve 8	2350	Curve 9	2400	Curve 10	2450	Curve 11	2500	Kurve 12
---------	------	---------	------	---------	------	---------	------	---------	------	---------	------	---------	------	-----------------	------	------------------	------	-----------------	------	-----------------	------	-----------------	------	-----------------	------	-----------------	------	-----------------	------	-----------------	------	-----------------	------	---------------	------	-------------------	------	---------------	------	------------------------	------	------------------	------	--------------------------	------	-------------------------	------	---------------------	------	------------------	------	------------	------	----------------	------	----------------	------	----------------	------	----------------	------	----------------	------	----------------	------	----------------	------	----------------	------	----------------	------	-----------------	------	--------------	------	----------------	------	---------	------	---------	------	---------	------	---------	------	---------	------	---------	------	---------	------	---------	------	---------	------	----------	------	----------	------	----------


---

**MEASURE**

O2 output [vol.%]

**20.9**

LI1 LI2 LI3 LI4



Remark: Not all warnings or faults can be reset. In this case eliminate the cause of the warnings or faults!



---

**LAMTEC Meß- und Regeltechnik  
für Feuerungen GmbH & Co. KG**

Impexstraße 5  
D-69190 Walldorf  
Telefon (+49) 06227 / 6052-0  
Telefax (+49) 06227 / 6052-57  
Internet: <http://www.lamtec.de>  
e-mail: [info@lamtec.de](mailto:info@lamtec.de)

**LAMTEC Leipzig GmbH & Co. KG**

Baalsdorfer Straße 55  
D-04299 Leipzig  
Telefon (+49) 0341 / 8653-312  
Telefax (+49) 0341 / 8653-396

**Presented by:**

Druckschrift-Nr. D LT 1002.01 aE 013  
Printed in the Federal Republic of Germany